



Rosy Complexion

Design courtesy of Slumpy's

Stop and smell the roses! Create this floral scone in just a few easy steps.

MATERIALS

CF-151-F Carolina Frit Cherry Red Transparent - Fine
CF-152-F 8 oz. Carolina Frit Ruby Red Transparent - Fine
CF-543.2-F 8 oz. Carolina Frit Grape Transparent - Fine
GBS-4x6-100-ICE Ice Clear Sheet Glass - 4" x 6"
SM-6231 Large Curve Mold (primed)
SM-9780 Organic Originals - Roses (primed)
ST-100 Diamond Glass Sanding Block

SUPPLIES

Cut Angled Straw
Small Paintbrush

INSTRUCTIONS

1. Lightly wipe ware with a damp sponge to prepare surface for painting.
2. Determine a 4" x 6" area on the pre-primed Roses Organic Originals texture mold to complete project design.
3. Within the determined area, use an angled straw to carefully fill in the textured rose designs with an assortment of fine Cherry Red, Ruby Red, and Grape Transparent Carolina Frit.
4. Use a small paintbrush to touch up any frit-filled areas of the design.
5. Position the 4" x 6" Clear sheet glass onto the texture mold. Place project into a kiln, then contour fuse using Spectrum's 5-segment firing schedule.
6. Once fired, cold-work the project using a Diamond Glass Sanding Block to smooth down the edges.
7. Slump project - textured side facing up - over the Large Curve Mold.